





第 13 章 抢占式多任务

汪辰



- > 抢占式多任务
- > 抢占式多任务的设计
- > 兼容协作式多任务



- ➤ 【参考 1】: The RISC-V Instruction Set Manual, Volume I: Unprivileged ISA, Document Version 20191213
- ➤ 【参考 2】: The RISC-V Instruction Set Manual, Volume II: Privileged Architecture, Document Version 20190608-Priv-MSU-Ratified
- > 【参考 3】: SiFive FU540-C000 Manual, v1p0



- > 抢占式多任务
- > 抢占式多任务的设计
- > 兼容协作式多任务




- ▶ **协作式多任务 (Cooperative Multitasking):** 协作式环境下,下一个任务被调度的前提是当前任务主动放弃处理器。
- ➤ 抢占式多任务 (Preemptive Multitasking): 抢 占式环境下,操作系统完全决定任务调度方案,操 作系统可以剥夺当前任务对处理器的使用,将处理 器提供给其它任务。



- > 抢占式多任务
- > 抢占式多任务的设计
- **兼容协作式多任务**


Task A









Task B














Task A




save previous context

switch context

restore next context

mret

Task B





code/os/08-preemptive/os.h

```
struct context {
    /* ignore x0 */
    reg_t ra;
    reg_t sp;
    .....
    reg_t t6;
    // upon is trap frame


    // save the pc to run in next schedule cycle
    reg_t pc; // offset: 31 *4 = 124
};
```




code/os/08-preemptive/entry.S

```
trap_vector:
        # Save all GP registers
        . . . . . .
        # save mepc to context of current task
                a0, mepc
        csrr
                a0, 124(t6)
        SW
        call
                trap handler
        . . . . . .
        mret
switch to:
        # switch current context
                mscratch, a0
        csrw
        # set mepc to the pc of the next task
       1w
                a1, 124(a0)
                mepc, a1
       csrw
       # Restore all GP registers
        mret
```











- > 抢占式多任务
- > 抢占式多任务的设计
- > 兼容协作式多任务

兼容 task_yield()



```
/*
 * DESCRIPTION
 * task_yield() causes the calling task to relinquish the CPU and a new
 * task gets to run.
 */
void task_yield()
```

RISC-V 中断(Interrupt)的分类

ISCAS MIST

- ➤ 本地 (Local) 中断
 - software interrupt
 - timer interrupt
- ➢ 全局 (Global) 中断
 - externel interrupt

——M mode Software Interrupt—	
———M mode Timer Interrupt—	
——M and S mode External Interrupt→	U54
	Hart1


Interrupt	Exception Code	Description	
1	0	User software interrupt	
1	1	Supervisor software interrupt	
1	2	Reserved for future standard use	
1	3	3 Machine software interrupt	
1	4	User timer interrupt	
1	5	Supervisor timer interrupt	
1	6	Reserved for future standard use	
1	7	Machine timer interrupt	
1	8	User external interrupt	
1	9	Supervisor external interrupt	
1	10	Reserved for future standard use	
1	11	Machine external interrupt	
1	12-15	Reserved for future standard use	
1	≥16	Reserved for platform use	

【参考 2】 Table 3.6: Machine cause register (mcause) values after trap.

【参考 3】Figure 3: FU540-C000 Interrupt Architecture Block Diagram.

Core Local INTerruptor





【参考 3】 Figure 3: FU540-C000 Interrupt Architecture Block Diagram.

CLINT 编程接口 - 寄存器 (software interrupt 部分)



可编程寄存器	功能描述	内存映射地址
MSIP	,最低位和 CSR mip.MSIP 对应。	BASE + 4 * (hart)

- ▶ 每个 Hart 拥有一个 MSIP 寄存器
- RISCV 规范规定, Machine 模式下的 mip.MSIP 对应到一个 memory-mapped 的 控制寄存器。为此 QEMU-virt 提供 MSIP, 该 MSIP 寄存器为 32-bit, 高 31 位不可用,最低位映射到 mip.MSIP。
- 具体寄存器编址采用 base + offset 的格式,且 base 由各个特定 platform 自己定义。针对 QEMU-virt,其 CLINT 的设计参考了 SFIVE, base 为 0x2000000。

#define CLINT_MSIP(hartid) (CLINT_BASE + 4 * (hartid))

CLINT 编程接口 - 寄存器 (software interrupt 部分)



可编程寄存器	功能描述	内存映射地址
MSIP	,最低位和 CSR mip.MSIP 对应。	BASE + 4 * (hart)

➢ 对 MSIP 写入 1 时触发 software interrupt,写入 0 表示对该中断进行应答。

```
code/os/08-preemptive/sched.c
                                                 code/os/08-preemptive/trap.c
void task yield()
                                                 reg trap_handler(reg_t epc, reg_t cause)
       int id = r mhartid();
        *(uint32_t*)CLINT MSIP(id) = 1;
                                                        if (cause & 0x80000000) {
                                                                switch (cause code) {
                                                                case 3:
  code/os/08-preemptive/entry.S
                                                                        int id = r mhartid();
  trap vector:
                                                                         *(uint32 t*)CLINT MSIP(id) = 0;
                                                                         schedule();
                                code/os/08-preemptive/sched.c.
                  trap handler
          call
                                                                         break;
                                  void schedule()
          mret
  switch to:
                                          switch to(next);
          mret
```





谢谢 欢迎交流合作